

Functional test of heat pipes:

To test the orderly function of a heat pipe, dip one end in hot water (approx. 50°C). The result is an immediately heating of the opposite side of the heat pipe. Therefore it does not matter, which side you put in the water.

